

Responding to the Anthrax Crisis

**Occupational Safety and
Health Branch, DS, ORS
National Institutes of Health
Applied Research Portfolio**



Why Has OSHB Become Involved in These Efforts?

- Support for emergency response personnel
- Response to NIH personnel's safety and health concerns
- Environmental sampling in mail handling facilities
- Microbiological screening of suspicious mail
- Inadequacy of Level A Laboratory response capabilities



Why Has OSHB Become Involved in These Efforts? (Cont.)

- **Development of a surrogate system for "weaponized" anthrax**
- **Inadequacy of standard Biological Indicators (BIs)**
- **Lack of enhanced or "weaponized" biological indicators**



Why Has OSHB Become Involved in These Efforts? (cont.)

- **Standardization of environmental sampling procedures**
- **Informal consultation with Dept. of State-Sterling SA-32**
- **Mail decontamination efforts**
- **Identification of chlorine dioxide as a viable decontamination method for mail (leading to partnering with CDG)**



OSHB Applied Research Portfolio

- Comparison and standardization of environmental sampling techniques
- Expansion of Level A Laboratory capabilities-addition of commercial biochemical and monoclonal antibody technologies
- Development of the enhanced or "weaponized" anthrax surrogate system



OSHB Applied Research Portfolio (cont.)

- **Generational mail cross-contamination experiments**
- **Decontamination of mail with high purity chlorine dioxide gas (in partnership with CDG)**
- **Development of enhanced biological indicators (in partnership with CDG)**



The Team

NIH

- Deborah E. Wilson, DrPH, SM, CBSP
- Murray L. Cohen, PhD, MPH, CIH
- Gail Katz
- John H. Keene, DrPH, SM, CBSP
- Katherine Lock
- Robert W. McKinney, PhD
- Theodore J. Traum, PE
- Jason Barr, MS

CDG

- Thomas E. McWhorter, *President and CEO*
- Aaron A. Rosenblatt, *Chairman*
- Diane Battisti, PhD, Principal Research Microbiologist
- Nick Franco, PhD, Research Chemist
- David H. Rosenblatt, PhD, Col, USAR (Ret.), Science Advisor



KILLING “WEAPONIZED” ANTHRAX

Briefing of TSWG
by

Occupational Safety and
Health Branch, DS, ORS
[REDACTED]



Introduction

US facilities and mail have been contaminated with Anthrax spores; they must be decontaminated.

In conventional sterilization, benign spores (*B. subtilis*) are used as surrogates (biological indicators, BI) for pathogenic spores (Anthrax).

The Anthrax spores of recent events have been "weaponized"—they are finely dispersed and small ($<5\ \mu$), highly concentrated ($\sim 10^{12}$) and aerosolize easily

Weaponization changes the spores' susceptibility to sterilization regimes—it makes them harder to kill.

Commercial *B. subtilis* BI's may not be appropriate surrogates for weaponized Anthrax spores. Inactivation commercial indicators does not permit concluding that "weaponized" anthrax has been killed.



Introduction

"Weaponization" (enhancement)—the ability to produce finely dispersed, highly concentrated, easily aerosolized, and sterilization-resistant spores— is a frighteningly simple process.

NIH/CDG have prepared "weaponized" *B. subtilis* BI's (WBIs), which are much harder to kill than commercial BI's, and which are proposed as appropriate surrogates for weaponized Anthrax.

Standard steam, EtO, formaldehyde and chlorine dioxide sterilization regimes are not effective against WBIs.

Special cycles (developed by CDG) using high-purity chlorine dioxide gas, have proved effective at killing WBIs. NIH has overseen the work, and performed the microbiological analyses.



Weaponization

The "weaponizing" Process:

- Concentrated spores are milled
- Ingredients added/ surfaces modified
 - Reverses the charge on spores
 - Selectively & strongly hydrophilic, protecting spores from re-hydration
- May initiate the activation signal preparing the spore for germination

The "weaponized" product:

10^{10} - 10^{12} spores per gram;
may be aerosolized and re-aerosolized;
 $1 \times 3 \mu$ geometry (~ asbestos) means likely that low dose required

The ease with which spores can be weaponized poses a continuing threat resulting in the need for continuing surveillance and countermeasures.



Weaponization

NIH testing: WBI⁶ vs. WBI¹⁰ vs. Conventional BI⁶
(superscript reflects # spores /strip)

Results: Conventional BI are not equivalent to WBI

Practical implications for ongoing decontamination work:

1. The Hart Building

2. Decontamination protocols—for mail and facilities--
must use cycles developed and validated against
enhanced surrogate challenges, using precise
parameters that are properly controlled and
documented. WBI use is indicated.

3. Decontamination is feasible, if properly carried out.



CDG

Background:

DH Rosenblatt— Edgewood Arsenal; Ft. Detrick (1960s)

Gordon, Kieffer & Rosenblatt (1972)

AA Rosenblatt et al— ClO₂ gas for R_x sterilization (~1980)

J&J— Purchases ClO₂ gas:R_x sterilization patents (1990)

CDG: ClO₂ for drinking water treatment (1992-)

CDG/DARPA: ClO₂ gas for facilities decon (2000-)



CDG

Current Work:

USPS Mail decontamination (proposed)

SafeMail™ Systems (in development)

USPS facilities decontamination (proposed)

WBI^x: Development of indicators to simulate high-concentration, sterilization-resistant weaponized spores (in partnership with OSHB,NIH)

Development and validation of cycles for the reliable, reproducible destruction of weaponized spores



CDG

Cycle development & validation:

Procedures and practices used for sterilization of medical devices
Statistical model, based on initial bio-burden and "log" kill.
Parameters must be precisely controlled and measured.
 ClO_2 gas must be pure.

Critical process variables:

ClO_2 concentration; time; temperature; relative humidity; pressure;
mass transfer

Other issues:

Materials compatibility (ClO_2 vs. Cl_2)

Effect of Light

Validation/reproducibility of results.

Parametric release— why correlated BIs are essential



CDG

Gas:Solid Technology




Pure chlorine dioxide gas (~8%, in nitrogen)

Precise, flexible control

Safe, simple operation.


Uses *Saf-T-Chlor*™ thermally stable solid sodium chlorite.








CDG Laboratory Mail Process Reactor



CDG Laboratory ClO₂ Generator and Process Controller



CDG Laboratory Humidification Chamber



Practical Implications for Decontamination

Facilities:

Competent preparation of the physical premises is required.

Humidity control is essential to killing pathogens and minimizing damage

Relatively-high gas concentrations are required

Pure ClO_2 minimizes damage, allows for accurate gas measurement

Mass transfer is relatively straightforward

Coherent measurement/documentation of all parameters is essential

Mail:

Pressure vessel is required

Pure ClO_2 , generated by gas:solid technology minimizes damage, allows for accurate gas measurement

Gas consumption is relatively minor

Mass transfer is critical

Coherent measurement/documentation of all parameters is essential



Mail Decontamination with High-Purity Chlorine Dioxide Gas

- 10,000 ppm ClO_2
- 4 hr treatment cycle
- Challenge 2.0×10^8 enhanced spores on swabs
- 16 separate tests (12/13/01-1/4/02)
- Results:
 - 0/16 positive indicating total kill at 10^8



Mail Decontamination with High-Purity Chlorine Dioxide Gas

Effect of Pre-humidification

- 10,000 ppm
- 4 hr treatment
- > 95% relative humidity; 95° F
- Varying humidification times
- Enhanced spores- 2.0×10^8 in sealed envelopes



**Effect of Pre-humidification Time
on Sterilization of Enhanced Spores with ClO₂ Gas**

Humid. Time	1 hr	2 hr	3hr
2x10 ⁸ Swab	0/2	0/2	0/2
WBI ¹⁰	0/2	0/2	0/2
BI-10 ⁶	0/2	0/2	0/2
Pos. Control	1.7x10 ⁸	1.7x10 ⁸	1.7x10 ⁸



Mail Decontamination with High-Purity Chlorine Dioxide Gas

Effect of Gas Concentration

- 4 hr treatment
- 1.5 hr pre-humidification
- > 95% relative humidity; 95° F
- Varying humidification times
- Enhanced spores- 2.0×10^8 in sealed envelopes



Effect of Gas Concentration on Sterilization of Enhanced Spores with ClO_2

ClO_2 Conc.	2500 ppm	1000 ppm	500 ppm
2×10^8	0/2	0/2	2/2
Swab			1.43×10^3
WBI ¹⁰	0/2	0/2	2/2
BI- 10^6	0/2	0/2	0/2
WBI ⁶			3/4
Pos. Control	1.7×10^8	1.7×10^8	1.7×10^8



Comparison of Biological Indicators at 500ppm ClO₂

Humidification Time	1 hr	2 hr	3hr
WBI ⁶	Pos	Pos	Pos
BI-10 ⁶	Neg	Neg	Neg
WBI ⁶ Pos. Control	Pos	Pos	Pos
BI-10 ⁶ Pos. Control	Pos	Pos	Pos



WBI¹⁰ vs. Commercial BI-10⁶

Efficacy of Steam Sterilization

- 15 min
- 121° C
- 20 psi

Results

- (after 15 hr incubation in thioglycollate broth)
- WBI¹⁰ Heavy growth with pellicle formation
 - BI-10⁶ No growth



Summary

- **Weaponized Anthrax poses a unique decontamination challenge.**
- **Standard BIs are unsuitable surrogates for weaponized spores.**
- **WB/s are proposed as suitable surrogates for weaponized spores.**
- **Weaponized spores are resistant to standard sterilization regimes.**
- **It is should be possible to kill weaponized Anthrax-- in mail and in contaminated facilities-- using proven, reliable, commercially available ultra-pure chlorine dioxide gas technology.**



Next Steps

Scientific Research

- Replicate testing of WBI⁶ and WBI¹⁰ for statistical significance
- Development, testing of WBI¹²
- Mass transfer experiments
- Quality assurance



Next Steps

Process Development & Engineering

- **Cycle Optimization:**
Time, Temperature, Humidity, Pressure &
Gas Concentration
- **Design & Fabrication of Full-scale System**
- **Logistics, Equipment Shakedown**
- **Quality Control**
- **Safety Review**



Next Steps
?

TSWG

